
IQOS ILUMA

User Guide


IQOS ILUMA™ Pocket Charger




IQOS ILUMA™ Holder



Charging



Charging Cable



Po	wer	Ad	a	oto	br

For the full user guide, Customer Care and Extended support services for IQOS users, visit

www.iqos.com/services

FEATURES AND SETTINGS

Can be turned on or off with the IQOS app*.

Please register by scanning QR code or log in on www.iqos.com/iluma and follow the instructions.

 IQOS app may not be available in your country.

Getting Started



TURN ON


Press and hold Pocket Charger Button for 4 seconds, then release; Pocket Charger Status Lights and Holder Status Lights will turn on slowly.



CHARGE HOLDER

Insert Holder into the Pocket Charger, to charge.

Holder Status Light will show Holder battery level.



CHARGE POCKET CHARGER

Before first use, fully charge your device with Power Adaptor and Charging Cable.

(approx. 135 min)

How to use your IQOS ILUMA[™]



1. INSERT TEREA TOBACCO STICK

Insert the TEREA tobacco stick to the line on filter until Holder vibrates and Light(s) pulse(s).

Heating starts automatically, or by pressing Button for 1 second.



2. BEGIN USE Start using once Holder vibrates and Lights stay fixed.



3. NEARLY COMPLETE


To signal the last 30 seconds or last 2 puffs, Holder will vibrate with Light(s) pulsing white.



4. REMOVE TEREA TOBACCO STICK

Remove used TEREA tobacco stick and dispose as per Safety Warnings and Instructions.


How to use your IQOS ILUMA[™]



5. RECHARGE HOLDER


Insert the Holder in the Charger for recharging.

Quick Tips



CHECK HOLDER STATUS

Tilt Holder towards you or short press Button, Holder Lights indicate Holder battery level.



CHECK HOLDER STATUS ON THE POCKET CHARGER

Short press Pocket Charger Button. Holder Status Light will turn on.



CHECK POCKET CHARGER STATUS

Short press Pocket Charger Button. Pocket Charger Status Lights will turn on to indicate battery level.



AUTOSTOP


During use, the experience will stop if the TEREA tobacco stick is moved, or removed from the Holder.

Quick Tips




LIGHT BLINKS YELLOW

Battery depleted, need to charge.




LIGHTS BLINK WHITE TWICE

IQOS ILUMA[™] is outside operating temperature range (0°C~40°C).



LIGHT BLINKS RED

Reset Pocket Charger. If red light blinking persists, contact Customer Care.



TO RESET

Place Holder in Pocket Charger and press Button for 10 seconds then release. All Status Lights will turn OFF, and turn ON, to confirm a RESET.

iqos ILUMA



This is the safety alert symbol. It is used to alert you to potential physical injury hazards.

SAFETY WARNINGS AND INSTRUCTIONS

PLEASE READ ALL SAFETY WARNINGS AND INSTRUCTIONS BEFORE USE TO AVOID INJURY.

These safety warnings and instructions cannot cover all possible conditions that could occur and users should exercise care and caution.

KEEP THESE SAFETY WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

These Safety Warnings and Instructions are applicable to IQOS ILUMA $^{\rm m}$ and IQOS ILUMA PRIME $^{\rm m}$

Intended Users

- IQOS ILUMA™, IQOS ILUMA PRIME™ and TEREA tobacco sticks are for adult use only.
- IQOS ILUMA™, IQOS ILUMA PRIME™ and TEREA tobacco sticks are for adults who would otherwise continue to use tobacco or nicotine-containing products.
- Children and adolescents should never use IQOS ILUMA™, IQOS ILUMA PRIME™ or TEREA tobacco sticks under any circumstances.
- This product should not be used by persons with reduced physical, sensory or mental capabilities or lack of knowledge unless they have been given supervision or instruction to use the product in a safe way and understand the hazards involved.

Tobacco and Nicotine

- · TEREA tobacco sticks contain nicotine, which is addictive.
- IQOS ILUMA™, IQOS ILUMA PRIME™ and TEREA tobacco sticks are not risk-free. The best
 way to reduce tobacco-related health risks is to quit tobacco and nicotine use altogether.
- Some users may experience abdominal pain, chest pain, choking sensation, cough, difficulty breathing, dizziness, dry mouth, dry throat, gingivitiis, headache, malaise, nasal stuffinese, nausea, mouth irritation, palpitations, throat irritation, and vomiting.
- Nicotine-containing products should not be used by people who have or are at risk of heart diseases, are diabetic, or are epileptic or are experiencing seizures.
- Nicotine-containing products should not be used during pregnancy or while breastfeeding. If you are pregnant, breastfeeding or think you may be pregnant, you should quit tobacco and nicotine use altogether.
- Stopping smoking or switching to IQOS ILUMA[™] or IQOS ILUMA PRIME[™] and TEREA tobacco sticks or other nicotine-containing products may require the adjustment of the closing of contain nacharrea (o.g. tracepinylline, closzapine, ropinirole).

 If you have questions about whether you should use IQOS ILUMA™, IQOS ILUMA PRIME™ or TEREA tobacco sticks given an existing health condition, you should consult a health care professional.

▲ IMPORTANT SAFETY INFORMATION

A WARNING Choking, Ingestion and Handling Hazard

Keep IQOS ILUMA™, IQOS ILUMA PRIME™ and TEREA tobacco sticks out of reach of children and pets at all times.

- CHOKING HAZARD TEREA tobacco sticks contain small metal parts with sharp edges.
- INGESTION HAZARD
 - Swallowed TEREA tobacco sticks can cause serious injury to internal organs due to small metal parts with sharp edges.
 - Swallowed TEREA tobacco sticks can pose a risk of nicotine intoxication.
 - If TEREA tobacco sticks are swallowed, seek medical attention immediately.
- HANDLING HAZARD Do not take apart TEREA tobacco sticks as they contain small metal parts with sharp edges. Always dispose of TEREA tobacco sticks immediately after use according to local waste disposal regulations.

A WARNING Electronic and Battery Hazards

Electrical Risks

Failure to follow these Safety Warnings and Instructions could result in fire, explosion, electric shock, injury, or damage to the product or other property:

- Only Intended Users should use IQOS ILUMA™ and IQOS ILUMA PRIME™.
- Do not use IQOS ILUMA™ or IQOS ILUMA PRIME™ where the use of electronic devices is prohibited.
- Do not charge or use IQOS ILUMA[™], IQOS ILUMA PRIME[™] or accessories if damaged, tampered with or broken.
- Do not use IQOS ILUMA[™] or IQOS ILUMA PRIME[™] if the battery appears to be leaking.
- Only charge IQOS ILUMA[™] and IQOS ILUMA PRIME[™] indoors, as indicated by symbol
 , using a manufacturerapproved Charging Cable (supplied in the box) and Power

Adaptor (supplied in the box), for charging purposes. Do not use accessories not approved by manufacturer. Refer to 'Technical Data' section and www.iqos.com for details applicable to the mobility kit you purchased.

- This product must only be charged using Safety Extra Low Voltage. Refer to the Technical Data section of this User Guide for details.
- Do not use, charge, or store IQOS ILUMA[™] or IQOS ILUMA PRIME[™] in places with high temperatures (such as inside a car in summer, or near heat sources such as radiators or fires).
- Do not use IQOS ILUMA™ or IQOS ILUMA PRIME™ where flammable materials, liquids and gases are present.
- IQOS ILUMA[™], IQOS ILUMA PRIME[™], Power Adaptor and Charging Cable should not be exposed to any liquid. Do not touch them if they become wet or have been immersed in any liquid.
- Do not clean the device with any cleaning agent.
- Clean the USB charging port of the IQOS ILUMA[™] and IQOS ILUMA PRIME[™] periodically to avoid accumulation of foreign matters (such as dust particles), and inspect USB port for foreign materials before using USB connector.
- Handle with care. Do not drop IQOS ILUMA™ or IQOS ILUMA PRIME™ or subject them to strong shock.
- This product contains no user-serviceable parts. Do not
 attempt to open, modify, service, disassemble or repair any

component of IQOS ILUMA $^{\rm M}$ or IQOS ILUMA PRIME $^{\rm M}$ or to replace any of the components or batteries.

- IQOS ILUMA™ and IQOS ILUMA PRIME™ Pocket Charger and Holder are not compatible with previous IQOS generations (IQOS 2.4, IQOS 2.4 PLUS, IQOS 3, IQOS 3 DUO). Do not attempt charging IQOS ILUMA™ or IQOS ILUMA PRIME™ Holder in any previous IQOS generation Pocket Charger. Do not attempt to charge any previous IQOS generation Holder in IQOS ILUMA™ or IQOS ILUMA PRIME™ Pocket Charger.
- Do not use this product if it has been exposed to excessive cold, heat or moisture.
- Do not touch IQOS ILUMA™ or IQOS ILUMA PRIME™ and/ or their accessories if they overheat, spark, fume, ignite, or burn. If applicable and possible, use caution to shut off or disconnect power supply.
- Do not attempt to insert any object in the heating chamber other than TEREA tobacco sticks.
- Device can only be operated $>0^{\circ}C/<40^{\circ}C$.
- TEREA tobacco sticks are single use only and should never be re-used, lit with a match, lighter or any other flame source.

Battery Risks

IQOS ILUMA™ and IQOS ILUMA PRIME™ are powered with sealed Lithium-ion (Li-ion) batteries. Under romal conditions of use, the battery is sealed. If you notice that battery fluid leaks, follow these precautions:

- If fluid from leaked battery is swallowed, seek medical attention immediately. Do not induce vomiting or ingest food or drink.
- · If vapor from leaked battery is inhaled, get fresh air and seek medical attention.
- If fluid from battery is in contact with skin, wash the affected area, including hands and do not touch eyes.
- If fluid from leaked battery is in contact with eyes, immediately flush with clean running water for at least 15 minutes and seek medical attention.

A CAUTION Thermal Burn Risk

Failure to follow these Safety Warnings and Instructions could result in thermal burns:

- Store IQOS ILUMA™ or IQOS ILUMA PRIME™ and TEREA tobacco sticks in a clean, dry, and cool place.
- Do not expose IQOS ILUMA™ or IQOS ILUMA PRIME™ and TEREA tobacco sticks to high humidity conditions or direct sunlight.
- · Do not use TEREA tobacco sticks that have been exposed to excessive heat or moisture.
- · Do not remove TEREA tobacco stick while in use.

Allergic Reaction Risk

- Using IQOS ILUMA™ or IQOS ILUMA PRIME™ and TEREA tobacco sticks could cause an allergic reaction, such as swelling of the face, lips, tongue, gums, throat, or body, difficulty breathing, or wheezing.
- Stop using IQOS ILUMA* or IQOS ILUMA PRIME** and TEREA tobacco sticks and seek medical attention immediately if you experience any of the symptoms above as they may indicate a serious allergic reaction.

Use of TEREA tobacco sticks

- Only use IQOS ILUMA™ and IQOS ILUMA PRIME™ with TEREA tobacco sticks specifically designed for IQOS ILUMA™ and IQOS ILUMA PRIME™ devices.
- Never use IQOS ILUMA[™] or IQOS ILUMA PRIME[™] with a cigarette or similar products.
- Do not use TEREA tobacco sticks with previous IQOS device generations (IQOS 3 DUO™ or earlier).
- Do not modify TEREA tobacco sticks in any way or add any substance to TEREA tobacco sticks. Doing so may cause injury.

Storage

- Device must be stored in a clean, dry, and cool place. Do not store in temperatures above $60^{\rm o}{\rm C}.$
- · Store in a place inaccessible to children.

Reporting of adverse events or incidents

- If you experience any unwanted health effect when using IQOS ILUMA™, IQOS ILUMA PRIME™ and/or TEREA tobacco sticks, consult a health care professional.
- You can report any adverse event or incident directly by contacting your local Customer Care (details can be found in the Customer Care & Warranty booklet). By reporting side effects, you can help provide more information on the safety of this product.
- · For more information please go to www.iqos.com

TECHNICAL DATA

Holder:

IQOS ILUMA™ and IQOS ILUMA PRIME™ Model C1402 Battery type: Li-ion rechargeable battery Input: 5 V === 1.6 A

Pocket Charger:

IQOS ILUMA PRIME™ Model C1502 Battery type: Li-ion

Input: 5 V ____ 2 A

Pocket Charger: IQOS ILUMA™ Model M0001 Battery type: Li-ion

Input: 5 V === 2 A Bluetooth® 5.0

The IQOS ILUMA[™] and IQOS ILUMA PRIME[™] Pocket Chargers are marked with the symbol D→CK followed by "SxxXxx," which indicates the IQOS ILUMA[™] and IQOS ILUMA PRIME[™] Pocket Chargers can only be charged using one of the approved Power Adaptor models listed below.

Power Adaptor:

Model: S52A21, S21A20, S21A22, S21A23, S21A25, S21A27, S82A40, S82A41, S82A42, S82A43, S82A45, S82A46 Input: 100 V-204 V-50-60 Hz 0.3 A Output: 5 V === 2 A Output: 5 V === 2 A Output wer: 10.0 W Average active efficiency: 79.0% No load power consumption: <0.09 W

Use with Charging Cable

INFORMATION FOR DISPOSING OF IQOS ILUMA[™] AND IQOS ILUMA PRIME[™]

Valid across European Union and EEA

This symbol on the product or on its packaging indicates that this product and its individual parts (including batteries) must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by bringing it to a designated collection point for the recycling of waste equipment by bringing it to a designated collection point for the recycling of waste equipment addition, waste batteries can be returned free of charge at the point of sale. The separate collection and recycling of your waste equipment the inter of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. Disposing of waste equipment as unsorted municipal waste (e.g. by waste incineration or information about where you can drop off your waste equipment for recycling, please contact your local city office, your local household waste disposal service or the shop where you purchased the product. The local importer of the product will provide for the financing of the treatment and recycling of waste equipment returned through these designated collection points in accordance with local requirements.

BATTERY REMOVAL INSTRUCTIONS (FOR DISPOSAL AND RECYCLING)

Batteries must not be removed by the consumer. At end of product life, only an authorized recycler may safely remove batteries by following the steps below.

IQOS ILUMA PRIME™ Pocket Charger (Model C1502):

- Step 1: The device should be fully discharged before disassembling it.
- Step 2: Remove/peel off the rubber pad from the Pocket Charger Wrap Cover.
- Step 3: Remove the 2 screws.
- Step 4: Remove Wrap Cover by sliding and wiggling vertically slowly away from Metal Housing, then remove the 2 screws of the frame.
- Step 5: Detach all Flexible Printed Circuits and connector to remove the charger Printed Circuit Board.

Step 6: Remove battery by tilting it up and dispose of according to local regulations.

IQOS ILUMA™ Pocket Charger (Model M0001):

Step 1: The device should be fully discharged before disassembling it.

Step 2: Remove Door Cover with fingers.

Step 3: Open door and unscrew bottom and top screw.

Step 4: Remove Charger Housing.

Step 5: Unscrew the electronic circuit board (1 screw only).

Step 6: Unplug battery connector on the circuit board. Do not cut battery wires.

Step 7: Remove battery by tilting it up and dispose of according to local regulations.

IQOS ILUMA™ and IQOS ILUMA PRIME™ Holder (Model C1402):

Step 1: The device should be fully discharged before disassembling it.

Step 2: Open the Ring.

Step 3: Open the retainer cap, slide out the assembly out from housing.

Step 4: De-solder the battery tab and lift it up.

Step 5: Remove battery and dispose of according to local regulations.

Confirmation of Compliance

Hereby, Philip Morris Products S.A. declares that IQOS ILUMA[™] and IQOS ILUMA PRIME[™] are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The official Declaration of Conformity may be found at: www.pni.com/declarationofconformity

IQOS ILUMA™ and IQOS ILUMA PRIME™ operate within 2.402 – 2.480GHz frequency band with a maximum RF output power below 10.0 dBm.

This device complies with the RF exposure limits and has been evaluated in compliance with portable exposure condition according to the EN 62311:2008.

Designed and manufactured under the authority of Philip Morris Products S.A., Quai Jeanrenaud 3, 2000 Neuchâtel, Switzerland.

Bluetooth[®]

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Philip Morris Products SA. and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

Further information regarding the firmware license for IQOS ILUMA™ and IQOS ILUMA PRIME™ is available at www.iqos.com.

Not all devices listed in these Safety Warnings and Instructions are included in this mobility kit.